




Installation Guide

rev 1.3: 08-Nov-2007



Thank you for purchasing the tvTray from H-Squared. Each tvTray is laser-cut, hand-crafted, and then tested for integrity prior to shipping. Please utilize this installation guide to properly install your tvTray. Should you need assistance, please visit us at www.h-sq.com.

Installation Instructions

First find a suitable location for the Apple TV. You should have at least 8 inches of horizontal clearance and 10 inches of vertical clearance. Also ensure that you have at least 2 inches of depth clearance. This is to provide sufficient space for heat dissipation and for wireless signals.

1. The tvTray can be secured to almost any wall using the supplied screws and wall anchors. In addition, the mount can be rotated 360 degrees along the wall. Choose the orientation that best suits your installation. The rear of the Apple TV will align with the small keyhole slot on the mount.



Do not use the tvTray wall mount in a horizontal mounting application. Doing so may damage the AppleTV or the tvTrayzz .

- Using the template supplied in this guide, screw the anchors through the holes using a phillips head screw driver until the anchor is flush with the wall. Don't overtighten. For a perfectly level mount, use a level guide in the template. For VESA mounting, screw the optional VESA screws through either the inner or outer VESA holes on the tvTray.
- Pass all of the cables behind the mount, so that the ends of the cables come out along the same side as the keyhole.
- Slide the Apple TV onto the mount such that the power supply hole is aligned with the keyhole and the guides slide into the space between the aluminum edge of the Apple TV and the rubber base. There will be some resistance.
- Insert the power cable to lock the Apple TV into place and then attach your A/V cables.


Note: If you have also purchased the optional light kit, simply insert the USB adapter to a powered USB port such as the port on the back of the Apple TV.

Care and Maintenance

The tvTray product line uses 1/4" (6.35mm) cast acrylic that should provide a lifetime of service. To ensure maximum life of your product, please take the following precautions:

- The operating temperature of the tvTray is about -30F (-34C) to 180F(82C). Exposure below freezing or extreme heat causes the material to contract or expand. Take care at lower temperatures as the material can become very brittle and crack if subjected to stress or shock.
- Clean the tvTray using a mild soap detergent and warm water. Do not use glass cleaner or any other abrasive solution as this will scar the surface.
- If your tvTray should become scratched, you can use an acrylic scratch remover to buff out the scratch. Most local plastic suppliers carry such a material. H-Squared also carries these products. If you wish to order, please contact us at minimountsupport@h-sq.com.

Level Guide



Hole Template

